

ISTRUZIONI PER L'INSTALLAZIONE DI BOTOLE DORI-FIRE (IN ALLUMINIO) DESTINATE A SOFFITTI IN GESSO:

Fase 1: Scegliere una posizione di installazione tale da evitare, ove possibile, interferenze tra la botola e i profili della struttura.

Fase 2: Realizzare il foro di montaggio secondo le dimensioni della botola, prevedendo una tolleranza di 3 mm per lato. Mantenere gli angoli del foro perfettamente a 90° per garantire la corretta installazione della botola.

Fase 3: Inserire la botola d'ispezione nel foro predisposto e posizionarla in modo che sia pronta per il fissaggio mediante avvitatura alla struttura in cartongesso.

Fase 4: Fissare la botola mantenendola in posizione mediante morsetti oppure sostenendola manualmente durante l'avvitatura. Utilizzare viti autoperforanti idonee, di lunghezza adeguata allo spessore della lastra di cartongesso.

Utilizzare un numero adeguato di viti in funzione delle dimensioni dell'anta. Posizionare le viti a una distanza massima di 10 cm l'una dall'altra, garantendo un fissaggio uniforme e sicuro.

Note:

Verificare attentamente che il foro di montaggio presenti la corretta angolazione degli spigoli, poiché un'errata esecuzione può compromettere la corretta apertura della botola.

Applicare questa procedura di installazione a tutte le botole Dori-Fire con spessori di 12,5 mm, 15 mm, 25 mm e 30 mm.

Lunghezze delle viti consigliate:

Spessore botola 12,5 / 15 mm: Vite auto-perforante Ø3,5 x 35 mm.

Spessore botola 25 mm: Vite auto-perforante Ø3,5 x 45 mm

Spessore botola 30 mm: Vite auto-perforante Ø3,5 x 55 mm

Apertura e chiusura:

Per aprire e chiudere l'anta interna della botola, premere sul pannello in gesso in corrispondenza del lato delle serrature.

INSTALLATION INSTRUCTIONS FOR DORI-FIRE ACCESS HATCHES (IN ALUMINUM) FOR PLASTERBOARD CEILINGS:

Phase 1: Choose an installation position that, where possible, avoids any interference between the access panel and the profiles of the supporting structure.

Phase 2: Create the installation opening according to the dimensions of the access panel, allowing for a tolerance of 3 mm on each side. Ensure that the corners of the opening are perfectly square 90° to guarantee the correct installation of the access panel.

Phase 3: Insert the inspection access panel into the prepared opening and position it correctly so that it is ready to be fixed by screwing it to the plasterboard structure.

Phase 4: Secure the access panel in position using clamps or by manually supporting it during the screwing operation. Use suitable self-drilling screws with a length appropriate for the thickness of the plasterboard sheet.

Use an adequate number of screws according to the size of the access door. Position the screws at a maximum distance of 10 cm from each other, ensuring uniform and secure fastening.

Note:

Carefully check that the installation opening has perfectly square (90°) corners, as an incorrectly prepared opening may prevent the access panel from opening correctly.

This installation procedure applies to all Dori-Fire access panels with plasterboard thicknesses of 12.5 mm, 15 mm, 25 mm, and 30 mm.

Recommended screw lengths:

Door's thickness 12,5 / 15 mm: self-drilling screw Ø3,5 x 35mm

Door's thickness 25 mm: self-drilling screw Ø3,5 x 45 mm

Door's thickness 30 mm: self-drilling screw Ø3,5 x 55 mm

Opening and Closing:

To open and close the inner door of the access panel, press the plasterboard surface on the side where the latches are located.